

1 and 2-Piece Bathing Units

1P/2P

1. Framed-in area must be square and 0"-1/4" wider than unit to be installed.
2. Level and square the unit in the opening both horizontally and vertically.
3. For anchoring, screw through the flange into to the studs.
Vertical attachment at 8" centers and horizontally at each stud.
4. Attach shimstock to the framing of the opening if necessary to increase stability between bathing unit and walls.
 - For units with a 1-1/4" or lower curb height, see "Installation Instructions for Showers with Low Profile Bottoms" **LPB1**
 - For units with a 1-1/2" or higher curb height, it is not necessary to use an anchoring adhesive in installation, as these units have a wood-core reinforced bottom without an integral factory leveling material.
5. Drill from inside of unit walls to accommodate plumbing fittings.

NOTE: 2-piece models are factory dry-assembled with screws and nuts. Disassemble to get it into the bathroom, assemble with silicone sealant on the mating surfaces and around the fastener holes and install as one piece. Finish with a small bead of silicone sealant in the joint.

